

Zone 2		Zone 3		Zone 4		Zone 5		Zone 6		Zone 7		Zone 8		Zone 9	
CAP 2 Civil Air Patrol - 2		EMS WEST <i>(Hospital Emergency Dept./Ambulance)</i>		EMS EAST <i>(Hospital Emergency Dept./Ambulance)</i>		INT Interagency <i>(Police/Fire/Ambulance)</i>		EMERGENCY Special Ops / Wx		STATE AID		V-Tac VHF National Common Tactical Radio Channels		DOH Dept. of Health	
CAP MAIN Civil Air Patrol - Main	1	Cnt EMS Central Region EMS	1	SC EMS South Central Region EMS	1	SF INT Sioux Falls Area INT	1	SP OP1 Special Operations 1	1	ST AID1 State AID - 1	1	M/A RPTR	1	DOH-BT DOH Bioterrorism	
CAP TAC Civil Air Patrol -Tactical	2	Rbd EMS Rosebud Region EMS	2	Chm EMS Chamberlain Region	2	Tkr INT Turkey Ridge Area INT	2	SP OP2 Special Operations 2	2	ST AID2 State AID - 2	2	M/A DIR	2	DOH 1 DOH Region 1	
CAP ADMIN Civil Air Patrol - Administration	3	MAR EMS Martin Region EMS	3	Wag EMS Wagner Region EMS	3	Ver INT Vermillion Area INT	3	SP OP3 Special Operations 3	3	ST AID3 State AID - 3	3	V-CALL 10	3	DOH 2 DOH Region 2	
SP OP1 Special Operations 1	4	PR EMS Pine Ridge Region EMS	4	Prk EMS Parkston Region EMS	4	Trp INT Tripp Area INT	4	SP OP4 Special Operations 4	4	ST AID4 State AID - 4	4	VTAC 11	4	DOH 3 DOH Region 3	
SP OP2 Special Operations 2	5	SH EMS Southern Hills Region EMS	5	Ynk EMS Yankton Region EMS	5	Mit INT Mitchell Area INT	5	SP OP5 Special Operations 5			5	VTAC 12	5	DOH 4 DOH Region 4	
SP OP3 Special Operations 3	6	RC EMS Rapid City Region EMS	6	SE EMS Southeast Region EMS	6	Brk INT Brooking Area INT	6	SP OP6 Special Operations 6			6	VTAC 13	6	SNS-CMD Strategic Nat. Stockpile - Command	
SP OP4 Special Operations 4	7	NH EMS Northern Hills Region	7	SF EMS Sioux Falls Region EMS	7	Wtn INT Watertown Area INT	7	SP OP7 Special Operations 7			7	VTAC 14	7	SNS 1 Strategic National Stockpile 1	
SP OP5 Special Operations 5	8	LEM EMS Lemmon Region EMS	8	Mad EMS Madison Region EMS	8	Web INT Webster Area INT	8	SP OP8 Special Operations8			8	VTAC 17	8	SNS 2 Strategic National Stockpile 2	
SP OP6 Special Operations 6	9	EB EMS Eagle Butte EMS	9	Mit EMS Mitchell Region EMS	9	Isb INT Isabel Area INT	9	NWS-W Nat. Wx Service - West			9	VTAC 17D	9	SNS 3 Strategic National Stockpile 3	
SP OP7 Special Operations 7	10	EMS 1 Extra EMS Channel 1	10	Hur EMS Huron Region EMS	10	Abr INT Aberdeen Area INT	10	NWS-C Nat. Wx Service - Central/NE			10	VTAC33	10	SNS 4 Strategic National Stockpile 4	
SP OP8 Special Operations8	11	EMS 2 Extra EMS Channel 2	11	Brk EMS Brookings Region EMS	11	Red INT Redfield Area INT	11	NWS-SE Nat. Wx Service - Southeast			11	VTAC34			
STFIR 1 State Fire - 1	12	EMS 3 Extra EMS Channel 3	12	Wtn EMS Watertown Region EMS	12	Hur INT Huron Area INT	12	STFIR 1 State Fire - 1			12	VTAC35			
STFIR 2 State Fire - 2	13	EMS 4 Extra EMS Channel 4	13	NE EMS Northeast Region EMS	13	Mil INT Miller Area INT	13	STFIR 2 State Fire - 2			13	VTAC36			
STFIR 3 State Fire - 3	14	EMS 5 Extra EMS Channel 5	14	Abr EMS Aberdeen Region EMS	14	Chm INT Chamberlain Area INT	14	STFIR 3 State Fire - 3			14	VTAC37			
	15	EMS 6 Extra EMS Channel 6	15	Red EMS Redfield Region EMS	15	WIN INT Winner Area INT	15	Wx-1 Weather Radio - 1			15	VTAC38			
	16	EMS 7 Extra EMS Channel 7	16	NC EMS North Central EMS	16	PIR INT Pierre Area INT	16	Wx-2 Weather Radio - 2			16	VFIRE22			
	17	EMS 8 Extra EMS Channel 8			17	Mob INT Mobridge Area INT	17	Wx-3 Weather Radio - 3			17	VFIRE23			
					18	PHL INT Philip Area INT	18	Wx-4 Weather Radio - 4			18	VFIRE24			
					19	MAR INT Martin Area INT	19	Wx-5 Weather Radio - 5			19	VFIRE25			
					20	BIS INT Bison Area INT	20	Wx-6 Weather Radio - 6			20	VFIRE26			
					21	RC INT Rapid City Area INT	21	Wx-7 Weather Radio - 7			21	VMED28			
					22	SH INT Southern Hills Area INT					22	VMED29			
					23	NH INT Northern Hills Area INT					23	VLAW31			
					24	FTH INT Faith Area INT					24	VLAW32			
											25	SARI		May 2013	

black – digital talk-groups

Red – analog (Non-digital) channels

SP OP 1 - (monitored 24/7)

Wx Radio channels - Rx-only

On-Off  
Volume knob



# Motorola XTS-2500 "Quick-Guide" for DOH Portable Digital Radios "Custom Scanner Edition"

Turn the "Zone knob" to change "Zones"

A-B-C rotating plate used to set-up the "custom" scan list

1. Keep on "A" for normal operations
2. The "noogie" to rotate the plate is found on the back part of the plate.


## Turning "Scanner" On & Off

**Turn On:** Press the  button... the screen shows two options.... press the  button to turn the Scanner "On" a "Z" should appear in the upper screen.


**Turn Off:** ...Press the  button twice and the "Z" will disappear from the screen.

## Custom Scanner Programming


Turn the A-B-C- rotating plate to "B"


A flashing "  will appear in the screen.

Bring up the channel you want to add or delete.

Press  button to select a channel to add (a "Z" should appear).

Bring up your next channel.

Press  button to delete a channel (the "Z" should disappear).

To review your selections keep pressing the  recall button.



When done building your list Rotate the A-B-C plate back to "A".



## Scanner Tips:

- Each Zone has a pre-programmed "hard" scan list installed by the dealer for your facility. Just turn to that zone & put "On" the scanner to scan those channels.
- The "custom" scan list (10 channels max) can go in between zones & include digital & analog channels.
- You have a few seconds to talk directly to a channel that pops up on your scanner, before it reverts back to scanning channels again.

## How to Change "Talk Groups" (also known as "channels")

1. Turn the Zone knob to the "Zone" where that Talk Group is located.
2. Press the  button (you will see a "talk group" blinking).
3. Click the 4-way Toggle Switch "left or right" to change the "Talk Group".
4. When you get to the channel you want press the  "home" button and your "Talk Group / Channel" is now changed.



On-Off  
Volume knob



Turn the **“Zone knob”** to change **“Zones”** (1,2,3, etc.)

**A-B-C** rotating plate used to set-up a **“custom”** scan

1. Keep on **“A”** for normal operations
2. The **“noogie”** to rotate the plate is found on the back part of the plate.



Speaker-mic. has a Rotating **“Swivel Clip”** in the back

Speaker -Microphone  
Volume knob

# Motorola XTS-2500 “Quick-Guide” For DOH Issued Digital Radios

## Turning **“Scanner”** On & Off

**Turn On:** Press the button... the screen shows two options.... press the button to turn the Scanner **“On”** a **“Z”** should appear in the upper screen.

**Turn Off:** ...Press the button **twice** and the **“Z”** will disappear from the screen.

## Scanner Tips:

- Each Zone has a pre-programmed scan list installed by the dealer for your facility.
- Just turn to that zone & put **“On”** the scanner to scan those channels.
- You have a few seconds to talk directly to a channel that pops up on your scanner, before it reverts back to scanning channels again.

## How to Change **“Talk Groups”** (also known as **“channels”**)

1. Turn the **Zone knob** to the **“Zone”** where that Talk Group is located.
2. Press the button (you will see a **“talk group”** blinking).
3. Click the **4-way Toggle Switch** **“left or right”** to change the **“Talk Group”**.
4. When you get to the channel you want press the **“home”** button and your **“Talk Group / Channel”** is now changed.